


Warning! The exploded views refer to the general model

Table_A

Pos.	Code	Previous code	Description	Notes	From:	To:
0001	FR6237060		ASS. PORTA SCH. DX AB 081 PENTAV			
0002	FR4718632	FR4718631	PRESSAC. ABB ADAPTA FLEX ASF13/PG9/90			
0003	FR4501502		GASKET [R] DOOR BF081 650X690			
0004	FR6419260		LOWER HINGE RH [R] AB PENTAV			
0005	FR614B240		ASS.PANN.INF.ANT. DX RAL 9005 081 PENTAV			
0006	FR112C330		FLANGE [R] UPPER DOOR RH			
0007	BN011GENDESCR		NON UTILIZZATO SU QUESTO MODELLO			
0008	FR5110120		FILTER BLK [R] 081 PENTAV 600X330X10			
0009	FR6358610		GRIGL. SUPP. FILTRO AB 081 PENTAV			
0010	FR6350400		PLASTIC DRAIN TRAY [R] GN 1/1 H. 50			
0011	FR2110980		SCREW [R] M5X10			
0012	FR2761070		ZINC NUT [R] M5X10			
0014	FR112B030		PLATE ZINC FOR WHEELS SP30/10			
0015	FR6810350		CASTOR [R]			
0016	FR6810360		CASTOR [R]			
0017	FR2118160		PIN [R] HOOK AB PENTAV			
0018	FR2118160		PIN [R] HOOK AB PENTAV			
0019	FR4407130		EXTERIOR FRAME COVER [R] GASKET SLAM PENTAV. BLAST CHILLER 081 L. 697			
0020	FR4407110		HORIZONTAL FRAME COVER [R] PENTAV.			
0021	FR6352111		GRIGLIA PROT. POST. ABB. 081 '14			
0022	FR1238870		GUIDE SHELF SUPPORT [R] L=345 AB 051:161 PENTAV			
0023	FR615C710		ASS.STRUTTURA REGGI GUIDE AB 081 PENTAV			
0024	FR1220521		SUPPORT [R] CONTAINER 051/081/121/161			
0025	FR966412		HOOK KIT [R] GUIDE SUPPORT AB PENTAV			
0026	FR112D230		SUPP.PORTASONDA SPIL PT1000 8-12-16 PENT			
0027	FR663A800		HEATED CORE PROBE [R] PT1000 L. 1,5M			
0029	FR2471990		F-CONNECTOR [C] SHOWER HEAD PIPE			
0031	FR4710700		PLASTIC CAP DRAIN BLAST CHILLER			
0032	FR6510011		DRAIN [R]			
0033	FR4740100		PROTECTION [R]			
0034	FR6510021		PIPE [R] 1 G ARFP 350L - PENTAV. BLAST CHILLER			
0035	FR4503020		GUARNIZIONE SALVAGOCCIA AB L= 734			
0036	FR1739920		COVER [R] EVAP. PIPES AB 051/081/121/161			
0037	FR2110840		SPACER [C]			
0038	FR910200		LOCK [R]			11/30/2016
0039	FR1168160		PERNO FILETTATO M5 A SCATTO ART.R 6333			11/30/2016

Pos.	Code	Previous code	Description	Notes	From:	To:
0040	FR996326	FR1168170	SPRING [R] PIN M5 kit 5 pz.		12/1/2016	
0041	FR112C280		FLANGE DOOR LH [R] 20°AB PENTAV			
0042	FR6419270		HINGE [R] LOWER LH AB PENTAV			
0043	FR6237360		ASS. PORTA SCH. SX AB 081 PENTAV			
0044	FR614B420		KIT PANN.INF.ANT.SX C/AGG. AB 081 PENTAV			
0045	FR112C300		PIASTR. CIECA AB PORTA SX PENTAV			




Warning! The exploded views refer to the general model

Table_B

Pos.	Code	Previous code	Description	Notes	From:	To:
0001	FR652A880		EVAPORATOR [R] BLAST CHILLER UL			
0002	FR2471920		CUFF [R] 3010 1/8-1/4			
0003	FR4618261		PIPE [R] 2,5X4MM			
0004	FR2118120		NOZZLE [R] PENTAV. BLAST CHILLER			
0005	FR6631540		AIR PROBE [R] PTC L. 2500			
0006	FR6631260		EVAPORATOR PROBE [R] PTC L. 2500			
0007	FR1342301		GAS CONVEYOR [R] CONDENSER			
0008	FR4740265		COLLAR [R]			
0009	FR6678670		FAN [R] D. 300			
0010	FR6351092		PROTECTION GRID [R] FAN D. 300			
0011	FR663B140		CONDENSER [R] 2,0 uF 416.10.31			
0013	FR4740286		VASCHETTA R.COND. AB P800 PA6 30% F.V.			
0014	FR2471930		STRAIGHT MALE CONNECTOR [R]			
0015	FR6860160	FR6860040	PRESSURE SWITCH [R] CRO-4-0/75			
0016	FR6850332		SOLENOID VALVE [R]			
0017	FR6851142		COIL [R] 220/240V 50/60HZ			
0018	FR4711850		GUSCIO ISOLANTE COZCRO04 X SPORLAN CRO4			
0019	FR323B390		@TUBO SCAMB. D=6-10-16 AB 081 50HZ PENT			
0020	FR6683010		COMPRESSOR [R] R404A 50HZ			
0021	FR6670590		FAN [R] D. 200 10W 50/60Hz			
0022	BN011GENDESCR		NON UTILIZZATO SU QUESTO MODELLO			
0023	FR6671420		COLLECTOR [R] FAN AB31/51/81/121			
0024	FR6671410		FAN [R]			
0025	FR6528790		CONDENSER [R]			
0026	FR6851210		ADAPTER [R]	Valv. Sanhua		1/30/2018
0027	FR6852620		ORIFICE [R] THERMAL THERMOSTATIC VALVE	Valv.Sanhua	8/1/2016	1/30/2018
0028	FR966446		KIT REPLACEMENT THERMOSTATIC VALVE [R] BF	Valv. Sanhua		
0029	FR6525570		FILTER [R] DRIER			
0030	FR6521550		TRAY [R] 0,58 LT			
0031	FR6635030		GAS PRESSURE SWITCH [R] HP			
0032	RF12G00009		ELET.VALV. 3VIE E371AM25/1/U35E 316 UL			
0033	FR2471960		NIPLES [R] 1/8-1/4			
0034	FR2471940		CUFF [R] 1/4			
0035	FR2471950		CONNECTOR [R] 3/4-1/4			
0036	FR6860000		RUBBER [R]			
0037	FR6860010		FILTER [R]			

Pos.	Code	Previous code	Description	Notes	From:	To:
0038	FR2471980		CONNECTOR [R] CIL1/4			
0039	FR323B440		PIPE [R] PENTAV. BLAST CHILLER 081			
0040	FR4740240		WATER DRAIN TRAY BLAST CHILLER NEW			
0041	FR5720110		SHEATH [R]			
0042	FR6622490		THERMOSTAT [R] 105Å°C/CAVO L=3MT PENTAV. B-CHILLER			
0043	FR2471930		STRAIGHT MALE CONNECTOR [R]			
0044	FR2472010		STRAIGHT MALE CONNECTOR [R] D. 6 M5			
0045	FR6935650		KIT CONDENS. H2O SALDOBRASATO ZC315			
0046	LA65060050		FAN [R] D. 120 4715MS 23T			
0047	FR1350200		PROTECTION GRID [C]			
0048	FR1224930		@STAFFA SUPP.COND.H2O B8+PRES+VAL.MONOBL			
0049	FR6630710		PRESSOSTATO HP KP5 DI ALTA 060-509666			
0051	FR6850520		VALVE [R]			
0052	FR1224872		STAFFA SUPP. KIT CONDENSATORE ACQUA '14			
0053	FR112C650		STAFFA AGGANCIO TUBO SCAR. VASC. EVAP AB			
0054	FR6851380		INDICATOR [R]			
0055	FR960965		L JOINT [R] WITH TUBE			



Warning! The exploded views refer to the general model

Table_C

Pos.	Code	Previous code	Description	Notes	From:	To:
0001	FR6622370UL	FR6622370	RES. CORAZ. 230V 500W 081 UL PENTAV			
0002	FR3410540		MOLLA FISSAGGIO RESISTENZE AB PENTAV			
0003	FR6621631		HEATING ELEMENT [R] 15W/M			
0004	FR30461017		GASKET [R]			
0005	FR6837660		@ASS.SC.EL. MONOF. AB 081 PENTAV			
0006	FR30664010		MORSETTIERA 3 POLI X 2,5 MM.QUADRI			
0007	FR6635190		EXPANSION BOAD [R] PHASE CUTTING 650W 50HZ PWM			
0008	FR663A670		PC BOARD [R] PENTAV. BLAST CHILLER			
0009	FR930182		CONTROL PANEL ASSEMBLY [R] PENTAV. BLAST CHILLER 051/081			
0010	FR663A660		DISPLAY [R]			
0011	FR5430260		GASKET [R] DISPLAY 7 PENTAV. BLAST CHILLER			
0012	FR5740270		CABLE [R] L. 0,5M			
0013	FR6639840		RELAY [R]			
0015	FR6639840		RELAY [R]			
0016	FR6641260		FUSE CARRIER [R] 10X38			
0017	FR995919		FUSE [R] 10A 10X38			
0018	FR6648590		FUSE CARRIER [R] 5X20			
0019	FR966117		FUSE [R] 500mA 5X20			
0020	FR6640291		MAGNETIC MICROSWITCH [R] DOOR			
0021	FR6691540		BALLASTCABLE [R] AR-TR			