



ELECTRIC FRYER 10lt.

Pos	Code	Description
0001	MA1031110222	BASKET [C]
0002	MACM229101	COVER [C] FRYER 10L
0003	MACM073100	HANDLE [C] MT/105
0004	MACM012401	NUT [C] M10X1
0005	MACM097900	GASKET OR [C] THERMOSTAT BULB
0006	MA1033515800	ELASTIC COUPLER [C]
0007	MACM216101	LIFTING DEVICE [C] HEATING ELEMENT FRYER 10L
0008	MA1037316601R	HEATING ELEMENT [C] 9KW FRYER 10L
0009	MA1046100800	FLANGE [C]
0010	MA1037111300	MICROSWITCH [C]
0011	MA15119299	GRAIN [C]
0012	MACM021600	RING NUT [C]
0013	MA52185099	KEY [C]
0014	MACM099200	GASKET [C] HEATING ELEMENT
0015	MACM200100	GREASE [C]
0017	MACM097701	THERMOSTAT [C] 230Â°C
0018	MACM187301	CONTACTOR [C]
0019	CR0587500	ORANGE PILOT LAMP [C]
0020	CR1095040	KNOB [C] SHAFT E15 D. 6
0021	CR0581190	BUSH [C]
0022	CR1095190	LABEL FRYER [C]
0023	CR0588510	GASKET [C] CONTROL PANEL 900
0024	CR0588950	EXTENSION [C] DRAIN PASTA COOKER 900
0026	CR0587650	GASKET [C] SHAFT
0027	CR0589660	THERMOSTAT [C]
0028	MA1037115100	FAIRLEAD [C] V-TEC PG16
0029	MA1037115200	LOCK NUT [C]
0030	MA1878400	TERMINAL BLOCK [C]
0031	CR0734670	EXTENSION [C] DRAIN
0032	MA1032100800	THROTTLE [C]
0033	MA1450500	DRAIN TAP [C]
0035	MA866000	CONNECTOR [C]
0036	MA866200	BICONE [C] D. 18
0037	MA1033702100	SUPPORT [C]
0038	MA1031113600	OIL FILTER [C] 10L FRYER TANK